

2. Setting Up/Manual Operation Geometrical Principles


System of coordinates

In order to control a lathe with a CNC-control system, the possible directions of movements are given names.

Transversal: X - axis

Longitudinal: Z - axis

These axes form the system of coordinates of the machine.



Coordinates

The point of intersection of the two axes is called the zero point.

If number values are indicated on the axes, then all target and actual positions of the workpiece or the tool can be described using the X and Z values.

When coordinates are used for dimensioning the parts to be turned, the diameter is indicated on the X-axis, and the length of the workpiece on the Z-axis.



The sign is used to indicate on which side from the point of intersection of the axes the described point is located.

- + in direction of the axis
- against the direction of the axis

Example

The coordinates of the described points are as follows:

P1:	X42	Z-35
P2:	X30	Z-21
P3:	X22	Z0
P4:	X-22	Z54
P5:	X-30	Z32
P6:	X-42	Z18




2. Setting Up/Manual Operation Geometrical Principles

Reference points

NC-zero point, workpiece zero point (W, symbol \oplus)


The coordinates of the individual workpiece depend, given absolute dimensioning, upon the position of the zero point.

The zero point can be redetermined by the programmer for each program and at any position within the work range. It is then called the NC zero point or workpiece zero point (W). The NC zero point is usually set to the turning center at the beginning of the workpiece.



Machine zero point (M, symbol \oplus)

As well as the work-dependent coordinate system with workpiece zero point, there is also a fixed machine coordinate system with machine zero. It is located on the turning axis on the spindle nose.



Reference point (R, symbol \oplus)

After switching on, the machine does not know where the machine slides are located. The measuring systems deliver signals only concerning the distance to be traversed (incremental position measuring system). This is why a reference point must be engaged (see REFERENCE operating mode).

Each slide axis has a reference mark.

The control system can compute the position of the mark relative to machine zero using parameters (see sect. 6).


When the slide crosses the reference mark, the control system starts counting and the relation between display and slide position is established.

Absolute dimensioning, incremental dimensioning

Drawings can be dimensioned by two methods:


1. All dimensions relate to one point.
This dimensioning method is called **absolute dimensioning**.

The X values are **diameters**.



2. The dimensions indicate the distance from the previous point.
This dimensioning method is called **incremental dimensioning**.

The X values are **radii**.



Depending on dimension data, target positions can be described to the control system by two methods:

1. To which point, relative to workpiece zero point, must the traverse be made?


This information applies to absolute dimensioning. It is designated by the command G90 in the program. Display on screen G90.

G90 takes effect automatically after switching on the control system and need not be programmed.

Example

```
N... G90 G1 X100 Z-100
```

The tool runs to point X100 Z-100 relative to NC zero point, independent of the actual current position.



2. By which measure should the tool traverse?

This information corresponds to incremental dimensioning.

It is indicated in the program by the function G91.


Display on screen G91.

The location of the workpiece zero point is irrelevant.

Example

```
N... G91 G1 Z-70
```

The tool traverses in negative Z direction by 70 mm opposed to the direction of the Z axis.




Detailed programming examples can be found in section 3.2 and 10.

Dimensioning system

Coordinate dimensioning (DIN 406) is used for the drawings in this handbook.

The zero point of the coordinate system is set to coincide with the workpiece zero point. The coordinates then correspond to the absolute dimensioning of the workpiece.



REFERENCE operating mode

Reaching reference point

In order for the slide to correlate with the measuring system, the slides must be traversed to the reference point. This is done in the REFERENCE operating mode. First the transversal slide (X), then the longitudinal slide (Z) reaches the reference point.

To reach the reference point, proceed as follows:



Press the operating mode key.

The operating modes menu is displayed on the screen.



Press the REFERENCE softkey

The reference menu is displayed on the screen as an empty menu



Press the CYCLE START key.

The reference point is now reached automatically by the control system.

Then the screen display shows:

When the reference point has been reached, then the display is active as determined by parameter N6.

END REFERENCE
SELECT OPERATING MODE



Press the operating mode key

The operating modes menu is displayed on the screen.

Note

If reaching the reference point is impossible, (e.g. due to a fixed roller steady, a clamped workpiece or because the reference was cancelled in parameter N3 by "1" instead of "0"), then the slides can be synchronized by the control system when "setting zero points" is selected in the **MANUAL CONTROL** operating mode.

MANUAL CONTROL Operating Mode

In MANUAL CONTROL operating mode, the slides can be traversed using the manual direction keys or handwheel. The machine is also set up in this operating mode.



Press operating mode key.

The operating modes menu is displayed.

Select operating mode



Press the MANUAL CONTROL softkey.

FEEDRATE MM/REV.	SPEED REV./MIN	V-CONST. M/MIN
TOOL SETTING MODE	T TOOL	SPINDLE SELECT. >
H-WHEEL X-AXIS 0.01	H-WHEEL Z-AXIS 0.01	MACHINE FUNC- TIONS



Press they "continue" key.

The following menu on the same level is displayed.

H-WHEEL X-AXIS 0.001	H-WHEEL X-AXIS 0.1	CLAMPING DEVICE
H-WHEEL Z-AXIS 0.001	H-WHEEL Z-AXIS 0.1	SPINDLE SELECT. >
FEED % ON/OFF	SPEED REV. % ON/OFF	CONTIN. FEED



Press the "continue" key

The second following menu on the same level is displayed:

		MANUAL PROGRAM SELECTION
FINISH TOOL INSPECTION	SPS G-FUNCTION	SPINDLE SELECT. >
DISPLAY SELECT.	DIAGNOSTIC MODE	

Slide movements using the manual direction keys

Enter feed (see second next page).



Slide can be traversed using the manual direction keys.



If the reference point has been reached beforehand, the display of the actual value shows the position of the tool nose according to the value programmed under parameter N6.

Slide movement by handwheel

Handwheel divisions are always metric.

Actuating a manual direction key or changing the operating mode cancels the preset handwheel setting.

The functions

HANDWHEEL X-AXIS 0.1

HANDWHEEL X-AXIS 0.01

HANDWHEEL X-AXIS 0.001

have the same practical significance.



Press HANDWHEEL X-AXIS
0.1 softkey

HANDWHEEL
X 0.1



Slide can be run in transversal
direction, using the handwheel.

The cross slide moves 0.05 mm
radius per handwheel division.
The diameter display changes
by 0.1 mm.



Press HANDWHEEL Z-AXIS
0.1 softkey.

HANDWHEEL
Z 0.1



The slide can traverse in
longitudinal direction using
the handwheel.

The longitudinal slide moves 0.1mm
per handwheel division.

Selection of a spindle

The ELTROPILOT L2 control system is designed for driving 3 spindles (auxiliary spindle for driven tool included).

The number of spindles which are present depends, however, on the type of the machine which is realized.

When the control system is switched on, the inputs and values displayed for feedrate, speed of rotation and cutting speed refer to the main spindle (M).

If another spindle is to be selected, then proceed as follows:

Status display SPINDLE M



Press the SELECT SPINDLE
softkey.

SPINDLE 1 is displayed in the
status line.

The renewed pressing of this softkey effects the switchover to spindle 2 and subsequently back to the main spindle.

spindle M = main spindle,
spindle 1 = driven tool,
spindle 2 = mechanically movable auxiliary spindle

Feed Input



Press FEED MM/REV.

G95 FEED MM (INCH)/REV. F:



Enter digits

F ... 100%
F ... NOM



Confirm

Control system uses set feed value.

If no entry is made at this point, the feed value entered in the parameters is active.

Feed override



Press the FEED % ON/OFF softkey

HANDWHEEL
F % % % %



Move handwheel.

HANDWHEEL
F % - 150 %
F ... %
F ... NOM

The feed override percentage set with the handwheel is active.



Press the FEED % ON/OFF softkey.

Handwheel feed override is switched off, the value last selected is retained. Changing the operating mode also switches off the existing handwheel allocation.



The current override can be altered again by renewed pressing of this softkey.

Constant cutting speed [m/min or feet/min]



Press V.CONST M/MIN

G96 V-CONSTANT S:



Enter digits

 I S ... 100%
 V ... NOM


Confirm

The main spindle uses the set cutting speed.

Note:

If spindle 2 is selected, the input refers to the auxiliary spindle and is executed with G296.

Speed input [Rev./min]



Press the SPEED REV/MIN softkey.

G97 SPEED REV/MIN S:



Enter digits

 I S ... 100%
 S ... NOM


Confirm

The control system works with the set speed.

Note:

If spindle 1 is selected, the input refers to the driven tool and is executed with function G98.
The spindle speed of the auxiliary spindle 2 is set with function G297.

Speed override



Press the SPEED % ON/OFF softkey

HANDWHEEL
S % % % %



Move handwheel

HANDWHEEL
S 50 % - 150 %

S %
S ... NOM

The speed override percentage set with the handwheel is active.



Press the SPEED % ON/OFF softkey.

Handwheel override is switched off, the value last selected is retained. Changing the operating mode also switches off the existing handwheel allocation.

Note

If SPINDLE 1 or 2 is selected, the input refers to the corresponding auxiliary spindle.

Machine functions



Press the MACHINE FUNCTIONS softkey

The following sub-menu is displayed on the screen:

COOL. 1 ON	COOL. 2 ON	COOLANT 1+2+3+4 OFF
COOL. 3 ON	COOL. 4 ON	M- FUNCTION MENU
SET UP MACHINE DIMENS.	APPROACH MACHINE DIMENS.	M- FUNCTION DIRECT



Press the COOL. 1 (2, 3, 4) on or COOLANT 1+2+3+4 OFF softkey.

By means of these softkeys, the coolant circuits can be activated or deactivated (if existing).

Selecting machine functions



Press the softkey
M-FUNCTION MENU

All existing M-functions can be activated using the following menus and the corresponding softkeys.

If the corresponding command of the M-function is known, then it may also be entered directly.



Press the softkey M-FUNCTION DIRECT

INPUT M-FUNCTION:



Enter the desired M-function in digits (for the meaning of the M-functions, see section 3.6)



Confirm

Corresponding machine function activated.

Indexing a spindle dividing device

If the spindle has a spindle dividing device (position-controlled M19), the selected spindle can be indexed with a rack which engages in an indexing gear. The control (SPS) retracts the spindle release in this process to avoid reversed rotation forces being exerted on the spindle dividing device due to the integral portion of the spindle control



Press the SPINDLES softkey.

The following submenu will appear.

MAIN SPINDLE ON CW	MAIN SPINDLE ON CCW	MAIN SPINDLE OFF
POINT STOP	INDEX ON	INDEX OFF

Main spindle is indexed.



Press the INDEX ON softkey.



Press the INDEX OFF softkey.

Rack indexing is disengaged.

Setting and approaching machine dimensions

Certain dimensions within the workspace can be stored as machine dimension 1 to 9 in the parameters N751 to N759 by entering the corresponding position or by approaching these positions by means of the manual direction keys.

These dimensions can be approached again, either automatically in the MANUAL CONTROL operating mode or via the parts program.



Press the SET UP MACHINE DIMENS. softkey.

ENTER NO. MACH. DIMENS.:



Enter digits (e.g.: 1)



Confirm

REACH MEAS. POINT +X AND/OR MENU KEY

>N 751 DIM. 1 -X 0.000 +X 0.000 -Z 0.000 +Z 0.000



Approach the position using manual direction keys.



Press the ACCEPT NEW VALUE softkey.

CONFIRM OR NEW INPUT:



Enter digits



Confirm

Entered value is accepted
 Note: The values refer to the zero point of the machine or the coordinate system of the machine, that is, the values for X are not regarded as diameter dimensions.

or



Confirm

The approached value is transferred to the selected parameter memory.

If the other dimensions (-X, +Z, -Z) are to be switched over to:



Press the MAINTAIN VALUE softkey.

Same procedure as for value X+



Press the SET DIMENS. INACTIVE softkey.

The selected dimension is set to ±9999.999.



Press the HANDWHEEL X 0.01 or Z 0.01 softkey.

The particular positions can be approached by traversing the slides by means of the handwheel.



Press the TERMINATE INPUT softkey.

Return to the main level of the setting menu.

If those dimensions stored under parameters N751 to N759 are to be approached, then proceed as follows:



Press the APPROACH MACH. DIMENS. softkey.

ENTER NO. MACHINE DIMENSION:



Enter digits



Confirm

ACTUATE MANUAL DIRECTION



Keep manual direction keys pressed down.

The corresponding slides are moved in the direction of the programmed dimension and stop there.



Press the END softkey.

Return to the main level of the setting menu.

Extended actual value display

If in addition to the "large" actual value display the spindle values etc. are to be displayed, the operator has to switch over to the extended actual value display (see also display configuration in chapter 0)



Press continue key if necessary.

The second follow-up menu of the MANUAL CONTROL operating mode appears.



Press softkey DISPLAY SELECT.

Switch-over to the extended actual value display. The mode of representation corresponds to the values programmed values under parameter N0006. If no reference run has yet taken place, an --- R --- appears instead of the relevant value.



Press again the softkey DISPLAY SELECT.

Switch-back to the normal actual value display.

Turning in longitudinal and transversal direction with constant feed

If a workpiece or a blank part is to be turned in longitudinal or transversal direction, the direction can be chosen using the following menu.



Press the **CONSTANT FEED** softkey.

SELECT DIRECTION FOR CONSTANT FEED:

	FACING +X	
TURNING LONGIT. -Z		TURNING LONGIT. +Z
	FACING -X	



e.g. press the softkey **FACING -X**.

ACTIVATE CONSTANT FEED BY "CYCLE START"



Press **CYCLE START**.

TERMINATE CONTINUOUS FEED ONLY BY "CYCLE STOP"



Press **CYCLE STOP**.

The facing process is performed until the button **Cycle Stop** is pressed.



Press the **HIGHER** key.

End of processing and return to the menu "continuous feed".

Return to the main level of the manual control operating mode.

Note

It is necessary to define the protection zones for the manual control operating mode before working with the continuous feed mode in order to prevent any collisions which might possibly occur.

During the turning process the tool movements should be watched closely, if necessary a low feed rate should be defined.

D-correction via handwheel

By means of this function the D-corrections derived "by hand" can be transferred into the corresponding parameter memory. D-corrections for the milling cutter diameter (DD) cannot be altered with the handwheel. They are only shown on the dialogue line together with corrections DX and DZ.



Press the HANDWHEEL ACTIVE D-CORRECT. softkey.

The currently active D-correction of the tool used at that moment is displayed in the dialog line:
D... DX +0.000 DZ +0.000 DD +0.000



e.g. press the HANDWHEEL X-AXIS 0.01 softkey.

HANDWHEEL 0.01



Moving the handwheel

The D-correction is displayed in the dialog line.



e.g. press the HANDWHEEL Z-AXIS 0.01 softkey.

HANDWHEEL 0.01



Moving the handwheel

The D-correction is displayed in the dialog line.



Press the TERMINATE HANDWHEEL CALCULAT. softkey.

The D-correction is accepted by the control system and transferred into the corresponding parameter memory.

Setting mode



Press the TOOL SETTING MODE softkey.

The menu for setting up is displayed.

TOOL GAUGING PROBE	TOOL CHANGE POINT	SET ZERO POINT
PROTECTIVE ZONES	T TOOL	ZERO POINT SHIFT
BACK-UP TOOL	SERVICE LIFE	M FUNCTION

Defining protective zones

The ELTROPILOT L2-control system provides the possibility in MANUAL CONTROL mode of defining protective zones outside of which the tool tip can no longer be moved: the “manually” established values are automatically transferred into parameter N0201. To set the individual limit values for the protective zones, proceed as follows:



Press the PROTECTIVE ZONES softkey.



Press the MAINTAIN VALUE softkey.

Displayed limit value is retained.



Press the PROTEC. Z. INACTIVE softkey.

The protective zone is set; the value 9999.999 appears.

If the value is to be altered:

Run slide to desired position with control keys.



Press the ACCEPT NEW VALUE softkey.

CONFIRMATION OR NEW INPUT



Confirm

Desired value is accepted.



Enter digits.



Confirm.

Entered value is accepted.

Proceed in the same way for limit values +Z, +X, -Z

If not all position values are to be altered:



Press the TERMINATE INPUT softkey.

Return to the SETTING MODE menu.

Tool change

Press the T TOOL
softkey.

INPUT TOOL NUMBER:

T5112

D51

DX 0.000

DZ 0.000



Enter digits.

Either 2-digit (Tpp):

tool file number =

position number = pp

With the 2-digit input of the tool
number an additional offset can be
programmed under parameter N12
(see section 6).

or 4-digit (Tnnpp):

Tool file number = nn

position number = pp

For example: Tool no. 51 is in the
turret at position 12, so enter
5112.



Confirm.

Turret position 12 is moved into
machining position. The tool data
(-lengths) were obtained from tool
file N1051.

Tool compensation **nn** is active.

2. Setting Up / Manual Operation

or as a 6-digit tool identity number:

TnnnOpp / iiiiii

tool file number = nn

tool position number = Opp

tool identity number = iiiiii

(For this purpose, parameter N1600 must be set to 1 and the tool reference list must be programmed appropriately; see description of parameters N1600 to N1664.)

For example: Enter 280455 if parameter N1651 is programmed as follows (N1651 51 ID 280455 T012).



Confirm

Turret position 12 is moved into machining position. The tool data (lengths) was/were obtained from tool file N1051.
Tool compensation nn is active.

T 51012 / 280455

D51

DX 0.000

DZ 0.000

If the tool control was switched on using parameter N1200, and tool life/batch size of the selected tool was determined under parameters N1201 to N1264, then the value for the **current tool life/batch size** is displayed between the T- and D-display.

The display in percentage values represents the current tool life/batch size relative to the programmed tool life/batch size (100%).

T 51012

01:54:12.0 73%

D51

DX 0.000

DZ 0.000

Note: In MANUAL CONTROL operating mode the control system does not count time/batch size.

Setting NC zero point

The function SET ZERO POINT determines the workpiece zero point. Usually this position is set on the turning axis in X and on the work face in Z.



Press the SET ZERO POINT softkey.

INPUT TOOL NUMBER:

Select setting tool



Enter tool number (e.g. of the setting tool). (Number can also be in 4 or 6 digits)

ACTUATE MENU KEY:

ACCEPT NEW VALUE	MAINTAIN VALUE	TERMINATE INPUT
WITHOUT PROTECTION ZONES		TOOL TYPE MENU
H-WHEEL X-AXIS 0.01	H-WHEEL Z-AXIS 0.01	



Confirm

Tool type is not altered.

If a different tool type is to be selected



Press the TOOL TYPE MENU softkey.

The tool type menu appears with a following menu on the same level.



Softkey for desired tool type selection.

Graphic support facility displays tool type.



Switch to left or right tool position if required.



Press the FURTHER TOOL POSITION softkey

Sets different tool position. (I and K signs of the file are automatically allocated to the selected tool position.)



Press the INPUT TOOL TYPE FINISHED softkey.

Selected tool type is defined; the cursor jumps to the next address parameter (FC). The selected tool type continues to be displayed on the monitor.

Color code for graphic simulation (option)

The color code determines the color of the tool path in graphic simulation.



Confirm color code or enter new code.

Scratching



Move in X-direction to scratch position, using manual direction keys or handwheel.

REACH MEASURING POINT IN X AND/OR MENU KEY:



Tool tip approaches scratch point in X.



Move away from part in Z direction only.

Slide moves away from workpiece.



Press the ACCEPT NEW VALUE softkey.

CONFIRMATION OR NEW INPUT:



Confirm.

Value is transferred to control system.

If workpiece zero is to be located on the turning axis, then enter the turned diameter.



Enter digits.

Entered value is transferred to the control system.



Confirm

REACH MEASURING POINT IN Z AND/OR MENU KEY.



Move in Z-direction to scratch position using manual direction keys or handwheel.

Tool tip approaches scratch point in Z on workpiece.



Move away from part in X-direction only.

Slide moves away from workpiece.



Press the ACCEPT NEW VALUE softkey.

CONFIRMATION OR NEW INPUT:



Confirm.

Value is transferred to the control system.

Enter zero if the workpiece zero point is to be located on the workpiece face.



Enter digits.



Confirm.

Entered value is transferred to the control system.

Workpiece zero is set with the setting tool.

If the value zero was entered for Z and the diameter for X, actual value display will be X0 and Z0 when the tip of the setting tool is located at workpiece zero.

The relevant tool offset is zeroed.

Enter tool data

The control system requests the data required for the desired tool type:

For the setting tool, enter zero for X and Z, for subsequent tools see next page.



Press the MAINTAIN VALUE softkey.

If the value is to be altered:



Press the ACCEPT NEW VALUE softkey.



Enter digits



Confirm

ACTUATE MENU KEY:

Displayed value is transferred.

INPUT TOOL PARAMETER OR CONFIRM:

Entered value is transferred to the control system.

After input has been completed, the actual value display contains the scratch value for X and Z, the tool data line contains the dimension value related to the setting tool. Thus, X0 and Z0 are given for the setting tool itself.

If input is to be terminated at a certain point:



Press the TERMINATE INPUT softkey.




Entering back-up tool

In order to be able to run a program with various different tools, the programmed workpiece contour may not be dependent on tool geometry.

If the zero point is set with the roughing tool, the value zero is allocated when the momentary slide position is scratched.

The finishing tool, for example, will not scratch at the same position. If the finishing tool is to be located at the workpiece zero point, the slides must be in a different position.

This correction of the slide position must be made for all tools.



To do this, the control system is equipped with a standard tool compensation facility.

The length difference in Z-direction and the offset in X-direction are called compensation values.

The sign determines the direction of compensation.

Example

Compensation in X: tool 2 must be corrected in the direction of the X-axis, i.e. +.

Compensation in Z: tool 2 must be corrected in the direction of the Z-axis, i.e. -.

For the back-up tool, two cases are differentiated:

1. Compensation values of the back-up tool to the setting tool are **unknown**:




Press the BACK-UP TOOL softkey.

Scratch and transfer values as for setting tool.

Note: By pressing the softkey WITHOUT PROTECTION ZONES it is possible to deactivate the protection zone monitor for the tool nose (N201) during the scratching procedure by the back-up tool, for example so that very long tools such as boring bars can also be scratched. The message WITHOUT PROTECTION ZONES then appears on the control screen above the dialogue line. In this case the operator must be extremely careful when moving the tool.

After exiting the tool set-up mode (softkey TERMINATE ENTRY), the control automatically reactivates the protective effect of parameter N201.



2. Compensation values of the back-up tool to the setting tool are **known**; e.g. for preset tools:



Press the BACK-UP TOOL softkey.

Enter the known compensation values for X and Z as parameters.

Tool change point (for machines with tool turret)

To change a tool, a slide position can be set within the working area.

This position is stored under parameter N202 TOOL CHANGE POINT.

This position can be engaged in the NC program with G14.

The numeric values relate to the machine zero point.

Note

The tool change point should be selected with particular care (consider all tools of the turret).

Danger of collision!



Press the TOOL CHANGE POINT softkey.

REACH MEASURING POINT IN X AND / OR MENU KEY

N202 TOOL CHANGE POINT
X... Z...

ACCEPT NEW VALUE	MAINTAIN VALUE	TERMI-NATE INPUT
H-WHEEL X-AXIS 0.01	H-WHEEL Z-AXIS 0.01	

If the value in X is to be retained:



Press the MAINTAIN VALUE softkey.

Value is maintained.



Traverse to X-value of the tool change point using manual direction keys and handwheel.



Press the ACCEPT NEW VALUE softkey

CONFIRMATION OR NEW INPUT



Confirm.

Engaged X-value for tool change point is transferred.



Enter digits.



Confirm.

Entered X-value for tool change point is transferred.

REACH MEASURING POINT IN Z AND/OR MENU KEY

If the value in Z is to be retained:



Press the MAINTAIN VALUE softkey

Value is maintained.



Traverse to Z-value of tool change point using manual direction keys or handwheel.



Press the ACCEPT NEW VALUE softkey.

CONFIRMATION OR NEW INPUT:



Confirm

Engaged Z-value for tool change point is transferred.



Enter digits.



Confirm.

Entered Z-value for tool change point is transferred.



Press the TERMINATE INPUT softkey.

Return to setup menu.

Zero offset

Once tool file data have been correlated, and if the original setting tool is no longer in the tool file, a new workpiece zero cannot be set without rendering the set tool compensation invalid. It is then simply a case of offsetting the zero point



Press the ZERO POINT SHIFT softkey.

REACH MEASURING POINT IN X AND/OR MENU KEY.

N50 NC-ZERO POINT X... Z...

ACCEPT NEW VALUE	MAINTAIN VALUE	TERMI-NATE INPUT
H-WHEEL X-AXIS 0.01	H-WHEEL Z-AXIS 0.01	

If the displayed X direction value is to be maintained:



Press the MAINTAIN VALUE softkey.

Original X-value is maintained.



Traverse to new zero point using manual direction key or handwheel.



Press the ACCEPT NEW VALUE softkey.

CONFIRMATION OR NEW INPUT



Confirm.

Engaged value is transferred to the control system.

X 0.000
Z



Enter digits.



Confirm.

Entered value is transferred to the control system.

Proceed accordingly for the Z-axis



Press the TERMINATE INPUT softkey.

Return to setup menu.

MANUAL CONTROL Operating Mode/Tool Measuring

Measuring in the manual control operating mode

If the machine is provided with the corresponding equipment, then the ELTROPILOT L2 control system allows for the measuring of tools within the working area of the machine in order to be able to determine the absolute lengths of a tool (presetter dimensions L and Q). This is done in the manual control mode, and the received values are transferred to the corresponding tool files.

There are three possibilities for measuring tool lengths in the manual control mode. These depend on the equipment of the machine:

- Measuring with an optical system
- Measuring with a measuring probe
- Scratching with respect to an input measure entered by the operator

Measuring with an optical system

The following conditions must be fulfilled:


- The crossed wires of the optical system are placed in a defined position in the working area of the machine. These measures must be entered as machine dimension 9 under Parameter N759 +X +Z.
- Under parameter N693 must be selected the type of measuring 2.

Principle of functioning

By means of the manual direction keys the tip of the tool to be measured is positioned near the crossed wires.

With the help of the handwheel and the optical system, the tool tip and the crossed wires are positioned congruently.

Then the control calculates the presetter dimensions L and Q of the tool using the difference between the measured value of the tool reference point N and the measure N759 of the crossed wires. The presetter dimensions are then transferred into the address parameters X and Z of the corresponding tool file.



Performing of measurement

Proceed as follows:



Select the manual control operating mode



Position the tool tip in front of the crossed wires using the manual direction keys



Press the TOOL SET-UP MODE softkey.

The set-up mode menu is displayed on the screen.



Press the BACK-UP TOOL softkey.

INPUT TOOL NUMBER



Enter digits.



Confirm.

ACTUATE MENU KEY
N10.. T.. WT FC X Z I K >
A B C D L



If necessary, enter tool type and color code.

REACH MEASURING POINT IN X AND/OR MENU KEY:



Press the HANDWHEEL X-AXIS 0.01 softkey.

The handwheel is activated.



Movement of the handwheel

Positioning of the tool tip in X-direction into the center of the crossed wires.



Press the ACCEPT NEW VALUE softkey.

X-value is transferred into the tool file.



Press the HANDWHEEL Z-AXIS 0.01 softkey.

The handwheel is activated.

REACH MEASURING POINT IN Z AND/OR MENU KEY:



Movement of the handwheel.

Positioning the tool tip in Z-direction into the center of the crossed wires.



Press the ACCEPT NEW VALUE softkey..

The value for Z is transferred into the tool file.

ACTUATE MENU KEY

If necessary, enter the addresses I, K, A, B, C, D and L.



Press the TERMINATE INPUT softkey

Return to the set-up menu.

Note

If the tool to be measured is a boring bar, then this is measured only in Z-direction. The control system takes the X-value from parameter N57 and enters it into the tool file.

Measuring with a measuring probe

For this, the following conditions must be fulfilled:

- The measuring probe is placed in a defined position within the workspace of the machine.
The value of this position must be entered as machine dimension 8 under parameter N758 +X +Z .
- Parameter N690 is used to switch on the in-process-measuring that is, the measuring circuit number 1 or 2 is selected.
- Under parameter N692 must be entered a measuring feed rate in [mm/min].

Principle


With the help of the manual direction keys the tool tip of the tool to be measured is positioned near the measuring probe.

By means of the manual direction keys and the measuring feed programmed in parameter N692 the measuring probe is started up and deflected in X-direction.

After a deceleration of a maximum of 20 milliseconds the axis drive is stopped.

In order for the NC to be able to monitor the measuring probe and for the probe to be deflected in Z-direction, too, the tool must be withdrawn by at least 5 mm against the direction of the starting movement.

Taking the difference between the measure of the tool reference point N and the measure of the measuring probe N758 the control system calculates the presetter dimensions L and Q of the tool and transfers them into the address parameters X and Z of the corresponding tool file.



Program execution

Proceed as follows:



Select the manual control operating mode.



Position the tool tip in front of the measuring probe by using the manual direction keys.



Press the TOOL SET-UP MODE SOFTKEY

The set-up mode is displayed on the screen.



Press the TOOL GAUGING PROBE softkey

INPUT TOOL NUMBER



Enter digits



Confirm

ACTUATE MENU KEY
N10.. T.. WT FC X Z I K >
A B C D L



If necessary, enter tool type or color code or press twice softkey MAINTAIN VALUE.

REACH MEASURE POINT IN X AND/OR MENU KEY:



Start-up the measuring probe in X-direction using the manual direction keys.

The tool tip approaches the probe in X-direction at a measuring feed rate defined under parameter N692. Then the tool tip is stopped there.
MEASURE VALUE X= ...
RETURN FROM MEASURING PROBE



Withdraw in opposite direction of the starting movement by using the manual direction keys.

The probe is again monitored by the NC.
REACH MEASURE POINT IN Z/ AND/OR MENU KEY:

When even the reference gauge ist to be calculated in direction Z, the following is to be effected:



Press softkey RETAIN VALUE

REACH MEASURE POINT IN Z/ AND/OR MENU KEY:



Start-up the probe in Z-direction by using the manual direction keys.

The tool tip approaches the probe in Z-direction at the measuring feed programmed under parameter N692. Then it is stopped there.
MEASURE VALUE X= ...
RETURN FROM MEASURING PROBE



Withdraw in opposite direction of the starting movement by using the manual direction keys.

The probe is again monitored by the NC.
REACH MEASURE POINT OR MENU KEY

Note:

Thereby the reference gauge can not to be fixed by input of numbers.



Using the manual direction keys, withdraw in opposite direction to the starting movement.

The probe is again monitored by the NC.
ACTUATE MENU KEY:

If necessary, enter I, K, A, B, C, D and L



Press the TERMINATE INPUT softkey.

Return to the set-up menu.

Note

If a milling tool is to be measured, then this is done only in Z-direction. The value for X is taken from parameter N57 and transferred to the tool file.

Scratching with respect to an input measure entered by the operator


On the previous pages (tool set-up mode) was described the scratching and fixing of the NC zero point by using the setting tool, to which then all follow-up tools refer (for this, parameter N693 must be set to zero). However, it is also possible to determine the absolute lengths of the tools by scratching without reference to a setting tool. The values determined are the presetter dimensions L and Q.

This technique of determining the absolute tool lengths is required when a tool is to be measured, but access to the crossed wires of the measuring optical system or the measuring probe is hindered by a clamped workpiece.

The following conditions must be fulfilled when using this technique:

- The NC zero point (parameter N50) must be determined and the X-value must **absolutely be zero**.
- Measuring type 1 must be selected under parameter N693.

Principle and program execution



After the scratching process, the diameter reached by this is transferred to the control by actuating the ACCEPT NEW VALUE softkey and by entering the value of the diameter in digits. Since the NC zero point is identical with the machine zero point as far as the X direction is concerned, the value reached by scratching refers directly to the machine zero. Into the tool file is entered the difference between tool reference point N and the scratching value as presetter dimension L under address X.

Then scratching is done in the Z-direction. The NC zero point in Z-direction is known, and also the distance between NC zero in Z and the scratching value in Z must be known. After scratching this distance is entered into the control system by actuating the softkey ACCEPT NEW VALUE and by entering this value in digits.

Thus the difference between tool reference point N and the scratching value is entered as presetter dimension Q under address Z into the control system. The actual execution of this scratching process happens in the same way as the scratching process described on the previous pages and is therefore not described in detail (see scratching with setting tool and follow-up tools referring to it).

MANUAL CONTROL Operating Mode

Entering tool service life

Entering the tool service life/batch size is possible both in the PARAMETER operating mode and in the MANUAL CONTROL operating mode where this is possible when in the setting up mode (see parameters N1200 to N1264). Furthermore the expired current tool life/batch size can be returned to the value of the originally programmed service life/batch size by actuating the ACCEPT PROGR. TIME softkey. Thus the tool diagnosis variables N1401 to N1464 are updated as well.



Press the TOOL SET-UP MODE softkey.

TOOL SETTING UP



Press the SERVICE LIFE softkey.

INPUT TOOL NUMBER:

If the service life/batch size of the current tool, i.e. the one that is connected, is to be updated, then proceed as follows:



Confirm.

N12.. T.. S AZ PS AS >

If the service life of another tool is to be updated:



Enter digits. (e.g.: 2)



Confirm.

N12.. T.. S PZ AZ PS AS >

The following submenu is displayed

ACCEPT NEW VALUE	MAINTAIN VALUE	TERMI- NATE INPUT
ACCEPT PROG. TIME		



Press the ACCEPT NEW VALUE

TYPE OF MONITOR. (TIME = 0,
PIECE = 1) or
INPUT PROGRAMMED SERVICE
LIFE OR CONFIRM:



Confirm.

Value is retained



Enter digits



Confirm.

Entered value is accepted



Press the RETAIN VALUE
softkey.

Cursor jumps to the next value

If all service life data have been updated, then also
the **D-compensations** for the tool concerned are offered
in dialog by the control system.

N1102 D2 X 0.000 Z 0.000 D 0.000



D-compensation values can now be
altered by actuating the correspon-
ding softkeys.

If the expired current service life is to
be reset to the value of the programmed
service life, then select the corresponding
tool and proceed as follows:



Press the ACCEPT PROGR. TIME
softkey.

Service life is reset to the
programmed value.



Press the TERMINATE INPUT
softkey.

Data input for service life is terminated
and input of D compensation is offered.



Press the TERMINATE INPUT
softkey again.

Return to the tool setup menu

Setting-up the chucking equipment

The chucking equipment can be set up by means of the handwheel. In the process, the C-axis can first be pre-positioned in the jog control mode to an angular value freely definable by the operator. The travelling speed desired at this time can also be defined by the operator. Subsequently the spindle can be moved to the exact target position with the handwheel. Furthermore this position can be transferred to the parameter memory N127 as the zero point of the C-axis (additive zero point shift). As an alternative, it is possible to transfer to the parameter memory the value travelled with the handwheel without moving the spindle (absolute zero point shift referred to the reference dimension of C-axis). When the control system is equipped with a position regulation unit, then the point stopping of the spindle can be adjusted using the handwheel as well. The values determined in that way can also be transferred to the parameter memory as zero point shift.



Press the CLAMPING
DEVICE SET-UP
MODE softkey.

The following menu is displayed on the monitor:

C-AXIS 1 SET-UP MODE		
		SPINDLE SET-UP MODE
		SPINDLE SELECT.

Positioning the C-axis in the jog control mode

Proceed as follows to position the C-axis in the jog control mode:



Press the C-AXIS
SET-UP MODE
softkey.

The following menu is displayed:

ACCEPT NEW	JOG	FINISH INPUT
ON	H-WHEEL C-AXIS	OFF
H-WHEEL C-AXIS 0.1	H-WHEEL C-AXIS 0.01	H-WHEEL C-AXIS 0.001

2. Setting Up / Manual Operation



Press the ON softkey.

The C-axis is swivelled in and executes a reference run
1 C 0.000



Press the JOG softkey.

ANGULAR VELOCITY C - 1:



Enter the digits in [degrees/min], e.g.: 80

ANGULAR VELOCITY C - 1: 80

Information: If a higher angular velocity is entered in the manual control mode than the one defined under the parameters, positioning is executed at the maximum speed defined in the parameters. The following note appears in the input line: "MAXIMUM VELOCITY FROM PARAMETER".



Confirm

ANGULAR VALUE C - 1:



Enter the digits, e.g.: 20

ANGULAR VALUE C - 1: 20.000



Confirm.

	1/MIN	DEGREES
CA1:	80	20.000



Jog

The C-axis rotates at the defined angular velocity in jog control mode and stops at the programmed position.

Moving the C-axis with the handwheel and setting the zero point
Proceed as follows to the exact position further with the handwheel:



e.g. press the H-WHEEL C-AXIS 1.0 softkey.

POSITION THE SPINDLE AND/OR PRESS MENU KEY



Turning the handwheel (e.g. by 10 dividing lines)

1C +10.000



Press softkey
TRANSFER NEW VALUE



Just confirm

IC 0.000

The actual-value display indicates the new position to which the C-axis was moved with the handwheel as the zero point. In parameter N127 +10.000 is stored as the zero point shift. A return branch then follows to the previous menu level.

Note: This type of zero point shift has an additive effect, i.e. when executed repeatedly, each of the individual shifts in parameter N127 is added to the existing value.

or



Digit entry (e.g. 30°)



Confirm

IC 30.000

The actual-value display indicates the new position in response to the digit entry, however the C-axis is not moved. Only the reading of the actual-value display shifts. This zero point shift is compensated in parameter N127, i.e. parameter N127 stands at minus 30.

Note: This zero point shift is not additive in effect; it is always absolutely referred to the reference dimension of the C-axis (0°).

or



Press softkey TERMINATE
ENTRY

The reading remains at IC +10,000 in the actual-value display. The spindle was moved 10°, however no zero point shift was carried out. Return to the next high menu level.

2. Setting Up / Manual Operation

Turning the spindle and setting the zero point (position-controlled M19)

If the control system is equipped with a position control (position-controlled M19), a point stop

adjustment of the spindle can be executed. After the spindle has been moved to position control, proceed as follows:



Press softkey SPINDLE
SET-UP MODE.

The following menu is displayed:

ACCEPT NEW VALUE.		FINISH INPUT
	H-WHEEL SPINDLE 1.0	
H-WHEEL SPINDLE 0.1		



e.g. press softkey HANDWHEEL
SPINDLE 1.0.

POSITION THE SPINDLE AND/
OR PRESS MENU KEY



Turning the handwheel
(e.g. by 25 dividing lines)

DEGREE
25.000



Press softkey ACCEPT
NEW VALUE.

The actual-value-display of the spindle
position displays the new position as zero
point.

In parameter N515 the value +25.000 is
stored as zero point shift.

Then the system returns to the previous
menu level.

or



Press softkey FINISH INPUT.
BEEENDEN drücken.

The actual value display continuously
shows DEGREES +25.000 .

Diagnosis as side-line operating mode

If the diagnostic mode is to be selected as side line
operation starting from this mode, then
proceed as follows:



Press the DIAGNOSTIC MODE
softkey.

The main menu of the diagnosis
operating mode is displayed (see also
section 7.1 "diagnosis operating mode
in side-line operation")

2. Setting Up / Manual Operation

G-functions evaluated by the SPS

If the G-functions (G600 - G699) evaluated by the SPS are to be executed in the manual control operating mode, proceed as follows:



Press softkey SPS G-FUNCTION.

ENTER G-FUNCTION:



Digit entry of the desired SPS function (if supported by the SPS)

G SPS RECORD WORD X:



Digit entry



Confirm

G SPS RECORD WORD Z:

Proceed in a like manner when entering the other address parameters.

If the last address parameter has been entered and/or confirmed, the function is evaluated by the SPS and the machine interface is configured accordingly

2. Setting Up / Manual Operation

Auxiliary programs for extensive movement sequences

For extensive sequences of movement which are to be repeatedly executed in the MANUAL CONTROL operating mode the ELTROILOT L2 control offers the option of filing these sequences in the control's program memory as auxiliary programs. 99 auxiliary programs can be stored; 1 to 9 are safeguarded with a password and stored in the control's program memory as MANUAL 1 to MANUAL 9. These programs have to be entered via punched tape or DNC operation and cannot be altered by the operator at the control in the EDITOR operating mode.

The operator can do as he wishes with programs 10 to 99 since they are not protected. Consequently they have only the flag %10 to %99 in the program memory and correspond to a normal parts program. Proceed as follows when calling an auxiliary program in the MANUAL CONTROL operating mode:



Press softkey MANUAL PROGRAM SELECTION

ENTER NO. FOR PROGRAM "MANUAL":



Digit entry (from 1 to 99)



Confirm.

The selected program is indicated.



Press CYCLE START.

The selected program is started at the first record and processed under the protection conditions of the operating mode AUTOMATIC.

Note: It is imperative to adhere to the operating steps shown here for starting a manual program. If a feed override, speed override or the like is initiated after selecting the manual program for example, instead of pressing the button CYCLE START directly, the program in question is not started and has to be activated again although it is still on the screen.

While the program is being executed, the handwheel can be used to override the speed and feed settings; the feed can be

interrupted by pressing the button FEED STOP.



Press the button CYCLE STOP, if applicable.

The processing of the particular auxiliary program is terminated immediately.

